

Widerstandstabelle KTY 10-5

Temperatur [°C]	Widerstand [Ohm]
-10	1459
-9	1472
-8	1485
-7	1498
-6	1511
-5	1525
-4	1538
-3	1551
-2	1565
-1	1578
0	1592
1	1605
2	1619
3	1633
4	1647
5	1661
6	1675
7	1689
8	1703
9	1717
10	1732
11	1746
12	1761
13	1775
14	1790
15	1805
16	1819
17	1834
18	1849
19	1864
20	1879
21	1895
22	1910
23	1925
24	1941
25	1956
26	1972
27	1987

Temperatur [°C]	Widerstand [Ohm]
28	2003
29	2019
30	2035
31	2051
32	2067
33	2083
34	2099
35	2115
36	2131
37	2148
38	2164
39	2181
40	2197
41	2214
42	2231
43	2248
44	2265
45	2282
46	2299
47	2316
48	2333
49	2351
50	2368
51	2385
52	2403
53	2421
54	2438
55	2456
56	2474
57	2492
58	2510
59	2528
60	2546
61	2564
62	2583
63	2601
64	2620
65	2638

Temperatur [°C]	Widerstand [Ohm]
66	2657
67	2675
68	2694
69	2713
70	2732
71	2751
72	2770
73	2789
74	2808
75	2828
76	2847
77	2866
78	2886
79	2906
80	2925
81	2945
82	2965
83	2985
84	3005
85	3025
86	3045
87	3065
88	3085
89	3106
90	3126
91	3147
92	3167
93	3188
94	3209
95	3230
96	3251
97	3272
98	3293
99	3314
100	3335

Toleranz Fühler = +/- 1% vom Widerstandswert